


GETTING THE MOST OUT OF YOUR

CASABLANCA SMART EDIT

(A compendium of Tips and Techniques for the Avio and Kron)

Volume I



Compiled and Edited

By

Carroll F. Lam

© Copyright 2001, 2002

TABLE OF CONTENTS

	Page
ACKNOWLEDGEMENTS	<i>Error! Bookmark not defined.</i>
DISCLAIMER	<i>Error! Bookmark not defined.</i>
RESTRICTIONS ON REPRODUCTION	<i>Error! Bookmark not defined.</i>
LIST OF ABBREVIATIONS	<i>Error! Bookmark not defined.</i>
INTRODUCTION	<i>Error! Bookmark not defined.</i>
OVERVIEW OF SOFTWARE CHANGES	<i>Error! Bookmark not defined.</i>
Project Settings Screen	<i>Error! Bookmark not defined.</i>
Record Screen	<i>Error! Bookmark not defined.</i>
Edit Screen	<i>Error! Bookmark not defined.</i>
Transition Screen	<i>Error! Bookmark not defined.</i>
Image Processing Screen	<i>Error! Bookmark not defined.</i>
Titling Screen	<i>Error! Bookmark not defined.</i>
Audio Record, Edit Screen	<i>Error! Bookmark not defined.</i>
Audio Mix Screen	<i>Error! Bookmark not defined.</i>
Finish Screen	<i>Error! Bookmark not defined.</i>
Other New Features	<i>Error! Bookmark not defined.</i>
DVD Arabesk V1.3 (included in Kron OS)	<i>Error! Bookmark not defined.</i>
SOME GENERAL TIPS	<i>Error! Bookmark not defined.</i>
Installation Tip	<i>Error! Bookmark not defined.</i>
Keyboard Shortcuts and Hotkeys	<i>Error! Bookmark not defined.</i>
Using PC-Link USB	[PC-LINK USB] <i>Error! Bookmark not defi</i>
For transfers to the Casablanca	Error! Bookmark not defined.
For transfers from the Casablanca	Error! Bookmark not defined.
WORKING WITH VIDEO CLIPS	<i>Error! Bookmark not defined.</i>
The SmartEdit Insert Function	<i>Error! Bookmark not defined.</i>
Quickly Checking An Edit At The End Of A Long Sb Clip	<i>Error! Bookmark not defined.</i>
WORKING WITH TRANSITIONS AND IMAGE PROCESSING F/X <i>Error! Bookmark not c</i>	
Minimizing Scene Creation Time	<i>Error! Bookmark not defined.</i>
Using Video Spicercrack	[Video Spicercrack] <i>Error! Bookmark not d</i>
Frames and borders.....	Error! Bookmark not defined.
Split screen f/x.....	Error! Bookmark not defined.

Moving frames	Error! Bookmark not defined.
Some PiP Studio Applications...	[PiP Studio]Error! Bookmark not
Adding soft frames	Error! Bookmark not defined.
'Blue spot' tracking.....	Error! Bookmark not defined.
Using a part of a video clip in a second clip	Error! Bookmark not defined.
'Moving title F/X	Error! Bookmark not defined.
Moving video backgrounds with two PiPs	Error! Bookmark not defined.
Using Motion Perfect... ..	[Motion Perfect]Error! Bookmar
Using Particle Magic... ..	[Particle Magic]Error! Bookmark r
WORKING WITH THE TITLER	<i>Error! Bookmark not defined.</i>
Using Video Spicerack To Enhance Your Titles... ..	[Video Spicerack]Error! Bookmark not
COMBINING AUDIO WITH VIDEO	<i>Error! Bookmark not defined.</i>
What Is The 'Timeline' Button For?.....	Error! Bookmark not defined.
Recording Audio From The Audio Mix Screen.....	Error! Bookmark not defined.
Audio Over-Modulation Indication.....	Error! Bookmark not defined.
Preventing The 'This will delete... audio sample!' Message.....	Error! Bookmark not defined.
RECORDING OUT TO TAPE	<i>Error! Bookmark not defined.</i>
The Effect Of Non-Drop Frame Timecode Editing.....	Error! Bookmark not defined.
HARDWARE HOW TO'S	<i>Error! Bookmark not defined.</i>
Using Firewire Transfers Between Casablancas.....	Error! Bookmark not defined.
Selecting a 'UPS'	Error! Bookmark not defined.
DVD TIPS	<i>Error! Bookmark not defined.</i>
Adding Projects.....	Error! Bookmark not defined.
Why Can't I Add My Project?	Error! Bookmark not defined.
Pre DVD Burning	Error! Bookmark not defined.
Testing the DVD	Error! Bookmark not defined.
Copying DVDs.....	Error! Bookmark not defined.